

# PUFAS Security Adhesive SK

## PUFAS Sicherheits-Kleister SK

Very high initial adhesion and moisture resistance also by problematical new plaster areas, aged plaster and plasterboards. Extra transparent.

**Areas of application:** *PUFAS Security Adhesive SK Paste* is suitable for all kinds of woodchip wallpapers, renovation and reinforcing fabrics, structured non-woven wallpapers, embossed and special wallpapers, vinyl and textile wallpapers as well as glassfibre.

**Technical data:**

Basic raw material:	methylcellulose, additives, synthetic resin powder
Bulk density:	approx. 0,43 g/cm <sup>3</sup>
pH-value:	approx. 8
Consumption	approx. 200 g/m <sup>2</sup>

**Surface preparation:** The surface has to be dry, firm and free of dust and grease. Remove old and loose wallpaper and distemper *PUFAS Wallpaper Remover*. Fill in cracks and holes with *PUFAS Interior or PUFAMUR Super Bonding Filler*. Pre-treat highly absorbent, sanding and chalking surfaces with *PUFAS Deeply-Penetrating Primer – solvent free*. Insulate water-soluble impurities, which may show through when wallpapering with *PUFAS Insulating Spray White*.

**Instructions:** Quickly pour *PUFAS Security Adhesive SK* into cold, clean water (see table) and stir briskly for a short time. Leave for 2-3 minutes and then mix again. Leave once more for 15 minutes and stir vigorously a last time.

Evenly apply the paste with a pasting machine directly onto the backside of the wallcovering or use a brush in necessary size. Hang the wallcovering following the instructions of the wallcovering manufactures. Dimensionally stable wallcoverings can also be applied directly onto the wall. Use a spreader or a short-haired lambskin role to evenly apply *PUFAS Security Adhesive SK* in the width of the strips onto the underground. Hang the wallcovering into the damp bed of paste und press down evenly with a moos rubber role or a paper-hanger spatula.

Moisten cladded wallcoverings on the back with a wet sponge before hanging. **Strictly follow the application instructions of the wallcovering manufacturers.**

Clean tools with water immediately after use.  
Wipe off any surplus paste on the wallpaper immediately with a damp sponge.  
Do not use if surface and/or room temperature is below +5° Celsius.

**Mixing ratio:**

for	Mixing ratio	Quantity of water per 800 g packet	Coverage of a 800 g packet	Quantity of water per 1.2 kg mechanically mixed	Quantity of water per 1.6 kg mechanically mixed
Pre-pasting	1:20	16 l	approx. 95 m <sup>2</sup>	24 l	32 l
Wallpapering machine/brush	1:15	12 l	approx. 65 m <sup>2</sup>	18 l	24 l
Role / spreader	1:12.5	10 l	approx. 45 m <sup>2</sup>	15 l	20 l
Maximum mixing ratio 800 g - no additional dispenses					

**Storage:** Store in a cool and dry place!

**Available sizes:**

800 g folding box	022902000
5 kg PE bucket	022904000